



1120 North Main Street • Elkhart, IN 46514
 PHONE: 574•264•2131 FAX: 574•206•9713
 INTERNET: <http://www.atwoodmobile.com>

HITCH BALLS

ENGLISH

•Installation •Operation •Maintenance

Effective 11/21/07

Safety Symbols alert you to potential personal safety hazards.
 Obey all safety messages following these symbols.

WARNING
 avoid possible
 injury or death

CAUTION
 avoid possible
 injury and/or property damage

FOR YOUR SAFETY READ ALL INSTRUCTIONS BEFORE INSTALLING HITCH BALL

Installer: Provide this instruction to consumer.
Consumer: Keep documents for future reference.

INSTALLATION

WARNING PERSONAL INJURY & PRODUCT DAMAGE

- The Atwood Ball is intended to be mounted on a drawbar or hitch platform located at the rear of the tow vehicle.
- Do not weld ball.
- Orient wrench flats parallel to towing direction.

1. Attach hitch ball to a platform no less than 3/8" thick. Refer to **TABLE 1** for maximum platform thickness.
2. Mounting hole must not exceed ball shank diameter by more than 1/16" thick.
3. Attach the drawbar with lock washer FIG 1A and nut FIG-1B supplied with ball. Always use a lock washer and position next to nut.
4. Threaded shank must protrude beyond bottom of nut when tightened.

OPERATION

WARNING PERSONAL INJURY & PRODUCT DAMAGE

- Do not exceed the lesser of the tow rating of vehicle, hitch, ball, coupler or trailer.
- Only use the hitch ball in conjunction with a socket type coupler matching the ball size.
- Never attach a tow rope, chain, cable or stretch-type elastic rope to ball for towing/pulling purposes.
- Replace ball if signs of cracking or flat spotting wear appear.

Replace at once any damaged or worn towing components if the ball shows signs of cracking or flat spotting.

Check nut tightness every time the trailer is hooked up and at the beginning of each towing day. Tow only if nut is tightened to specified torque see **TABLE 1**.

MAINTENANCE


1. Daily clean and lubricate ball and coupler with bearing grease to minimize wear and friction. Lubricate moving or sliding parts with S.A.E. 30 weight oil. Coupler must not bind on ball.
2. Check towing hitch, ball and coupler for signs of wear and damage each time the trailer is hooked and at the beginning of each towing day. Replace hitch ball if damaged or worn.

Should problems or questions arise, contact your dealer, the trailer manufacturer or Atwood Service Department 1-574-262-2655. **Contact Atwood before having any warranty work done.**

TABLE 1

PART #	84137	80212	80202	82551	80201
BALL SIZE	2-5/16"	2-5/16"	2"	2"	2"
*BALL CAPACITY (LB.)	40,000	13,000	8,500	6,000	5,000
TORQUE (FT.LB.)	560-600	560-600	560-600	170-200	170-200
MAX. PLATFORM THICKNESS	3/4"	3/4"	17/32"	11/16"	11/16"

*The capacity of the ball is the maximum gross vehicle weight of the tow vehicle.



1

Atwood Hardware Systems & Components Limited Warranty

Atwood Mobile Products warrants to the Original Owner of Atwood Hardware Systems & Components that Atwood will replace or repair any hardware systems and components that are defective in material or workmanship under the following conditions.

1. For two (2) years commencing with the date of purchase, Atwood, at their discretion, will replace or repair any Hardware System & Components that are found to be defective by Atwood in material or workmanship.
2. In the event of a warranty claim, the Original Owner must contact the Atwood Consumer Service Department, 1120 North Main St., Elkhart, IN 46514, Telephone: 574-264-2131 Fax: 574-206-9713. Warranty claim service must be performed as approved by the Atwood Consumer Service Department. Warranty replacement hardware systems and components or parts will be furnished freight prepaid. Labor cost to repair or replace will be limited to the amount of the original purchase price of the systems and components. The replaced warranty products or parts become the property of Atwood Mobile Products and must be returned to the Atwood Consumer Service Department freight prepaid, unless prior arrangements have been made.
3. This limited warranty is valid only when the product is applied, installed, maintained and operated in accordance with this Atwood Installation, Maintenance and Operating Manual. Any deviation from these recommended specifications must be approved in writing by Atwood.
4. Any implied warranties are limited to the duration of this limited warranty as stated above. Atwood does not assume responsibility for consequential damage or loss, including loss of use of vehicle, loss of time, inconvenience, expense for gasoline, telephone, travel, lodging, loss or damage to personal properties, or loss of revenues. Some states do not allow limitations on how long an implied warranty lasts or limitations on consequential damages, so the above limitations may not apply to you. This limited warranty gives you specific legal rights which may vary from state to state.