



## **LEVELEGS™ SYSTEM**

MANUALLY DUMP THE AIR BAGS

Effective 12/13/07

## For Atwood® LEVELEGS™ SYSTEM

Atwood Levelegs<sup>™</sup> Levelers are intended for use on recreation vehicle motorhomes and trailers.

## TO MANUALLY DUMP THE AIR BAGS

- a. Engine must be running.
- b. Transmission must be OUT of Park/Neutral.
- c. Parking brake must NOT be engaged.
- d. Atwood Levelegs keypad is NOT on.
  Lights inside the ON switch are not lit.
- e. Press the FRONT + REAR + ALL buttons to dump air from air bags. (Note: Air dump feature does need to be enabled for this feature to work.)
- f. Air bags dump in approximately 20 seconds and air bags refill 60 seconds from the start of the air dump.

For complete LEVELEGS™ SYSTEM instructions consult MPD 66166.

## **Aftermarket Replacement Service Part**

Quarter page actual size (Shown enlarged)